

# TOTAL COMFORT PLAN

**\$35.75** per month with EasyPay / **429.00** per year

The Total Comfort Plan covers everything the Value Plan covers, plus just about anything that's likely to go wrong with your heating system. Like the Value Plan, it includes an annual tune-up to increase your system's longevity and performance.

Wood's Heating will repair or replace, at no extra charge, any of the following parts which may become defective due to normal use or wear and tear.

*(The parts listed below are also covered by the Value Plan and the Value Plus Plan. The Total Comfort Plan, however, also covers the parts and services listed in the blue box.)*

## CONTROLS

- Aquastat
- Burner Mount Relay
- Burner Switch
- Cad Cell Eye
- Cad Cell Relay
- Circulator Relay
- Combination Control
- Double Aquastat
- Draft Regulator
- Emergency Switch
- High Limit Control
- Low Limit Control
- Pony Relay
- Pressuretrol Control (steam)
- Primary Relay
- Pyrostat
- Reverse Aquastat
- Stack Relay
- Thermal Safety Switch
- Thermostat (manual)
- Toggle Switches
- Triple Aquastat
- Triple Aquastat Relay

## WARM AIR SYSTEMS<sup>(1)(2)</sup>

- Air Filter (one std disposable set per year during tune-up)
- Airstat
- Blower Bearings
- Blower Fan
- Blower Fan Belt
- Blower Motor (up to 1/3 hp)
- Blower Pulley
- Blower Shaft
- Blower Wheel
- Fan Limit Control
- Limit Control

<sup>(1)</sup> On heating systems only; coverage does not apply if component fails while operating as a central cooling system.

<sup>(2)</sup> Parts and labor covered if A/C Start & Check purchased along with heating system plan.

## BURNER REPLACEMENT PARTS

- Air Shutter
- Air Stabilizer
- Burner Blast Tube
- Burner Cables
- Burner Capacitor
- Burner Fan
- Burner Fan Coupling
- Burner Flange Gasket
- Burner Fuel Unit
- Burner Head
- Burner Housing Assembly
- Burner Master Control
- Burner Motor
- Burner Switch

- Buss Bar Transformer Leads
- Cad Cell Assembly
- Cad Cell Wires
- Delayed Oil Valve
- Delayed Oil Valve Coil
- Electrode Assembly
- Electrode Leads
- Electrodes
- End Cone
- Hydraulic Jack
- Ignition Leads
- Ignition Transformer
- Ignition Transformer Gaskets
- Ignition Transformer Terminal
- Ignition Wiring
- Low Voltage Wiring (within 10 feet of boiler)
- Nozzle
- Nozzle Adapter
- Nozzle Assembly
- Nozzle Line
- Porcelain Insulators
- Retention Head
- Solenoid Valve
- Transformer
- Turbulator

## FUEL SUPPLY PARTS

- Fill Cap
- Firromatic Valve
- Fuel Filter Canister
- Fuel Filter Cartridge
- Fuel Filter Cartridge Gasket
- Fuel Pump
- Fuel Pump Bellows
- Fuel Pump Bleeder
- Fuel Pump Couplings
- Fuel Pump Fittings
- Fuel Pump Gasket
- Fuel Pump Needle Valve
- Fuel Pump Seal
- Fuel Pump Strainer
- Oil Tank Gauge
- Oil Tank Vent Alarm
- Vent Cap

## HOT WATER SYSTEMS

- Bearing Assembly
- Circulator Complete
- Circulator Coupling
- Circulator Impeller
- Circulator Motor
- Circulator Motor Mounts
- Circulator Switch
- Circulator Wicking
- Zone Valve
- Zone Valve Complete
- Zone Valve Motor
- Zone Valve Powerhead
- Zone Valve Relay
- Zone Valve Stem

## OTHER

- Anti-Hum Device
- Flue Pipe
- Glass Gauge
- Glass Gauge Washer
- Low Voltage Transformer

## TOTAL TUNE-UP INCLUDED

An annual tune-up will be performed once during the service agreement term during regular working hours.

## LOYALTY CREDITS

\$50 per year. Maximum credits: \$500.

Boiler—\$500    Furnace—\$400    Central A/C—\$250  
Oil Tank—\$200    Water Heater—\$200    Burner—\$100

**Please refer to the Value Plan/Value Plus Plan service contracts for information about optional coverage:  
Oil-Fired Water Heater—\$104; TankSure®—\$48.95; A/C Start & Check—\$139 (\$135 with heating system plan)**

**These additional parts and services are covered only by the TOTAL COMFORT PLAN.**

### PARTS

- Air Scoop
- Altimeter Gauge
- Automatic Air Vents (boiler)
- Automatic Water Feeder
- Baffle (forced hot air)
- Balance Valves
- Blower Circuit Board
- Blower Complete
- Boiler Valves
- Check Valves
- Clock Thermostat (standard Honeywell)\*
- Combustion Chamber (up to 2 gallons/hour)
- Draft Inducer\*\*
- Draft Inducer Circuit Board\*\*
- Draft Inducer Motor\*\*
- Dual Valve
- Expansion Tank
- Extrol Tank
- Feed Valve
- Flow Control Valve
- Gate Valves
- Globe Valve
- High Pressure Regulator
- Humidifier Fan\*\*\*
- Humidifier Float\*\*\*
- Humidifier Motor\*\*\*
- Humidifier Pad (one per year)\*\*\*
- Humidistat\*\*\*
- Low Pressure Regulator
- Low Water Cutoff Float
- Low Water Cutoff Switch
- Mixing Valves (for domestic hot water)
- Pop Safety Valve

- Preference Relay
- Pressure Reducing Valve
- Purge Valve
- Relief Safety Valve
- System 2000 Manager
- Temperature Gauge
- Trol-A-Temp

\* Only if installed by Wood's Heating  
\*\* Not power ventor  
\*\*\* Hermidifer only

### SERVICES

- Venting of baseboard or radiators (during tune-up only)
- Adjusting boiler pressure (during tune-up only)
- Adjusting water level (during tune-up only)